5 ISS TU-12 / SERVICE NOTES CHROMATIC TUNER TU-12-

Third Edition

NOTE

Note that both TU-12A and TU-12 are marked "TU-12" on their panels.

NOTE

Note that both TU-12HA and TU-12H are marked "TU-12H" on their panels

ますので、注意してください。


なっていますので、注意してください。


TABLE OF CONTENTS

How to distinguish between TU-12A/12HA(new) and TU-12/12H(old) **SPECIFICATIONS(new type) METER ADJUSTMENNT** PARTS LIST(new type) CIRCUIT BOARD(new type) CIRCUIT DIAGRAM(new type) SPECIFICATIONS(old type) PARTS LIST(old type) CIRCUIT BOARD(old type) CIRCUIT DIAGRAM(old type)

TU-12HA,TU-12H どちらもパネル面の表示は "TU-12H" と

目次 Page TU-12A/12HA (新バージョン) と TU-12/12H(旧バージョン)の見分け方 ···1 仕様 (new type) ······1 メーター調整 ・・・・・・・・・・・・・・・・・1 パーツリスト (new type) · · · · · · · · 2 基板図 (new type) ······2 仕様 (old type) · · · · · · 3 パーツリスト (old type)3 基板図 (old type) · · · · · · · 4 回路図 (old type) · · · · · · · · 4






Printed in Japan B0CE (DP) 1

How to distinguish between TU-12A/12HA(new) and TU-12/12H(old)

TU-12A/12HA



(Fig.A)

る為に、「INPUT」(又は「OUTPUT」)ジャックを見て下さい。

To distinguish between TU-12A/HA(new) and TU-12/12H(old), see the INPUT or OUTPUT jack(Fig.A) and check the serial number(Table.1).

If the jack is silver(Metal), it must be TU-12/12H(old type). If the jack is black(plastic), it must be TU-12A/12HA(new type).

銀色 (金属) TU-12A/12HA(新バージョン)とTU-12/12H(旧バージョン)を見分け

TU-12A/12HA(新バージョン)と

TU-12/12H

OUTPU

Silver(Metal)

TU-12/12H(旧バージョン)の見分け方

もし、ジャックが銀色(金属)なら、TU-12/12H(旧バージョン)です。 もし、ジャックが黒色(プラスチック)なら、TU-12A/12HA(新バー

又、シリアル・ナンバーからも新旧バージョンを確認することができ ます。(Table.1 参照)

Differnce Between TU-12A/12HA(new) and TU-12/12H(old)

(Table

TU-12A/12HA(新バージョン) と TU-12/12H (旧バージョン)の違い

1)		TU-12A/12HA (NEW)	TU-12/12H (OLD)
	Carriel No.	QE97100-up (TU-12A)	Prior to QE97100 (TU-12)
	Serial No.	DF05250-up (TU-12HA)	Prior to DF05250 (TU-12H)
	DOD Asserble	7843751000 (TU-12A)	79306530 (TÜ-12)
	PCB Assy No.	7843851000 (TU-12HA)	79307510 (TU-12H)

SPECIFICATIONS/仕様 (new type)

•	, ,
	: Power/Mode Selection Switch, PITCH Button, DOWN Button, UP Button: NOTE Name/PITCH Indicator, Meter Tuning Guide Indicators
Jacks	input Jack, Output Jack, AC Adaptor Jack
● Input Impedance · · · · · · · · · · · · · · · · · · ·	····:: 1M Ω
Standard Pitch ·····	· · · : 440Hz to 445Hz 1Hz step
● Tuning Range · · · · · · · · · · · · · · · · · · ·	····: TU – 12 :C1 (32.70Hz) to B5 (987.77Hz)
	TU-12H :C1 (32.70Hz) to B6 (1975.53Hz)
● Tuning Accuracy · · · · · · · · · · · · · · · · · · ·	· · · : ± 1 cent
Power Supply · · · · · · · · · · · · · · · · · · ·	····: DC9V : Dry Battery(9V type)
• · · · · · · · · · · · · · · · · · · ·	AC Adaptor(PSA - Series : option)
● Current Draw · · · · · · · · · · · · · · · · · · ·	
Dimensions ······	: 127/M/\ > 52/D\ > 25/H\mm
• Dimensions	
	$5 - 3/8(W) \times 2 - 1/16(D) \times 1 - 3/8(H)$ inches
● Weight ·····	····: 1/0 g / 6 oz
• Accessories ······	· · · : TU-12A Soft Case (22010740)
	TU-12HA Soft Case (22010738)
	Dry Battery(9V type) (12569103RT)
	TU-12A Owner's Manual(English) (2602080200)
	TU-12A Owner's Manual(Japanese) (2602080100)
	TU-12HA Owner's Manual(English) (2602081200)
	, , , , , , , , , , , , , , , , , , , ,
	TU-12HA Owner's Manual(Japanese) (2602081100)
	TU-12HA Syakuhachi Manual(Japanese Only) (26020814)
	TU-12HA Koto and Syamisen Manual(Japanese Only) (26020813)
Options · · · · · · · · · · · · · · · · · · ·	····: AC Adaptor; PSA - 100, PSA - 120, PSA - 220, PSA - 240
•	Dry Battery;S - 006P/9V(6F22/9V),6AM6/9V(alkaline)
	· · · · · · · · · · · · · · · · · · ·

METER ADJUSTMENNT

- 1. While holding down PITCH, switch the unit ON. The unit enters test mode.
- 2. Adjust CR1 so that the pointer stays in the 0 cent (center of the meter face).
- 3. Switch the unit OFF to exit the test mode.

メーター調整

- 1. PITCHを押しながら電源を入れる。 (テスト・モードに入る。)
- 2. CR1 を調整して指針をゼロセント(目盛中央)に合わせる。
- 3. 終了すれば電源を切りテスト・モードから出る。

PARTS LIST/パーツリスト (TU-12A/TU-12HA)

AITTO EIGT/ · ·	
SAFETY PRECAUTIONS:	
The parts marked \(\triangle \) have safety-related characteristics. Use only listed parts for replacement.	
安全上の注意:	
小が付いている部品は、安全 上特別な規格でつくられたも のです。 交換の際は、指定された部品 番号以外の部品は使わないようにして下さい。	

パーツ発注に関するお願い 御協力をお願いします。

2201061900	TU-12A	Top Case	Gray	
2201062000	TU-12A	Bottom Case	Grav	
2202064400	TU-12A	Battery Cover	Gray	
2201064200	TU-12HA	Top Case	White	
2201064300	TU-12HA	Bottom Case	White	
2202068000	TU-12HA	Battery Cover	White	

7843751000

TU-12A MAIN Board

NOTE: MAIN Board does not include Meter.
注意 : 補修用 MAIN 基板はメーターを含みません。
NOTE: Replacement MAIN Board includes SW Board
注意 : 補修用 MAIN 基板は SW 基板を含みます。

TU-12HA MAIN Board 7843851000

NOTE: MAIN Board does not include Meter. 注意 : 補修用 MAIN 基板はメーターを含みません。 NOTE: Replacement MAIN Board includes SW Board

:補修用MAIN基板はSW基板を含みます。

KNOB, BUTTON/	ソマミ、	ボタン
2247023700	Slide	Switch
2247053300	Tact	Switch

POWER/MODE SW PITCH SW, DOWN SW, UP SW SWITCH/スイッチ SLB2360-9 00019390 POWER/MODE SW PITCH SW, DOWN SW, UP SW

13129721 EVQ-QS1-07K JACK,SOCKET/ジャック、ソケット HEC0470-01-630 YKB21-5012 13449711 13449145 YKB21-5010

Adaptor Jack OUTPUT

POTENTIOMETER/ポリューム 00019312 EVM-38GA00B23 DISPLAY UNIT/ディスプレイユニット

Trimmer 2kB

7 Array LED, LED1-7 # LED, LED8

TUNING GUIDE LED, LED9, LED10

For POWER/MODE SW Knob. Orange

2243040300 Meter

00019367	SC412237FU	Mask CPU	IC1
15189251	M5218AP	OP AMP	IC4
00019412	S-81250HG-Z	REGULATOR	IC2
00019467	S-80728AN-Z	Battery Level Detector	IC3
DIODE LEDIAL.	/ + - K ED		

GL-107R8 SLP-144-40 SLP-139B 15029346 15029144

15029143 15019125 155-133 1SR139-100-T-32

CRYSTAL/ クリスタル

15299216	DSMAT310 4MHz			Xtal	
RESISTER/抵抗					•
00120012	CRB20T36EFX9763	(metal film)	976k	R17	
00120023	CRB20T36EFX4753	(metal film)	475k	R18	
00120034	CRB20T36EFX2403	(metal film)	240k	R19	
00120045	CRB20T36EFX1203	(metal film)	120k	R20	
00120056	CRB20T36EFX6042	(metal film)	60.4k	R21	
00120067	CRB20T36EFX3002	(metal film)	30k	R22	
00120078	CRB20T36EFX1502	(metal film)	15k	R23	
00120101	CRB20T24EFX5102	(metal film)	51k	R26	
00120089	CRB20T36EFX4702	(metal film)	47k	R27	
WIRING/ワイヤリ	ング				

00019256 MAJ-5X26-94-3 CONNECT MAIN Board with SW Board

MISCELLANEOUS/その他 12389308 Codenser Mic WM-54BY

1000000	Codesider wife with oad r		
00019223	LED Holder A	For	NOTE/PITCH LED
00019201	LED Holder B	For	# LED `
00019212	LED Holder C	For	TUNING GUIDE LED
00019234	LED Spacer	For	# LED
2341741401	Battery Connector		
22230568	Battery Cushion		
00019245	Saran Net	For	MIC.

ACCESSORIES/付属品

Plate

00120001

22010740	TU-12A Soft Case	Black
22010738	TU-12HA Soft Case	Beige
12569103RT	Dry Battery (9V type)	
2602080200	TU-12A Owner's Manual (English)	
2602080100	TU-12A Owner's Manual (Japanese)	
2602081200	TU-12HA Owner's Manual (English)	


2602081100 TU-12HA Owner's Manual (Japanese) TU-12HA Syakuhachi Manual (Japanese Only) 26020813 TU-12HA Koto and Syamisen Manual (Japanese Only) [TU-12A] MAIN BOARD

ASSY 7843751000

[TU-12HA] MAIN BOARD ASSY 7843851000 MAIN Board does not include Meter. 補修用MAIN基板はメーターを含みません。

NOTE

Replacement MAIN Board includes SW Board 補修用MAIN基板はSW基板を含みます。




View from component side.

Difference Between TU-12HA PCB and **TU-12HA PCB**

TU-12A PCB と TU-12HA PCB の違い

· ·				
	TU-12A	TU-12HA		
Jumper 1	0	Nothing		
Jumper 2	Nothing	0		
Jumper 3	0	Nothing		
Resistor 35 (100 Ω)	Nothing	0		

CIRCUIT DIAGRAM/回路図



□ L3055 TU-12| SERVICE NOTES

First Edition

SPECIFICATIONS

 $\textbf{Power Consumption}: 9V \ DC \ @ \ 20mA$

Tuning Range : C₁ (32.70Hz) to B₆ (1975.53Hz)

Accuracy : ±1 cent

Master Oscillator : Quartz (3.579545MHz)


Standard Pitch Dimensions

Pitch : 440 to 445Hz 1Hz steps **145**(W) x 35(H) x 53(D)mm

Printed in Japan BE-2

5-7/16 x 1-3/8 x 2-1/16 in

Weight : 170g 6 oz



PARTS LIST

2201064200 2201064300		TU-12H TU-12H	ELECTRET C 12389302	ONDENSER MIC WM-034BX		
2202068000		TU-12H	0000741			
2201061900	Case (top)	TU-12	CRYSTAL	0.570545841		
2201062000	Case (bottom)	TU-12	12389712	3.579545MHz		
2202064400	Cover (battery)	TU-12	METER			
2247023700	Knob (power)	:	2243040300	GM261-R3090A		
2247053300	Button (PITCH, DOWN, UP)		2226033300	Cushion	(TU-12 met	er)
2341041400	Battery snap 1007#24		IC			
14.07			15179140	MBR1012-523	CPU	
JACK	111 10500 01 110 (INDUT)		15219126	LC7900	Generator/D	Nividor
13449125	HLJ0520-01-110 (INPUT)		15189151	LA6458S or 455		rividei
13449126	HLJ0520-01-010 (OUTPUT)		10100101	OP Amp, SIP 9P	00	
13449711	HEC0470-01-630 (AC adaptor)	15229809	BA634		TU-12H
SWITCH				D7 (00 1		10-1211
13159323	HSW0520-01-010 slide (power))	DIODE			
13129721	EVQ-QS1-07K light touch		15019209T0	S5500G		
	(PITCH, DOWN, UP)		15019303	RD5.6JB2	(zener)	TU-12
РСВ				SN up to 294000		
79306530	MAIN BOARD		15019304	RD6.2JB2	(zener)	TU-12
70000000	(pcb 2291057704	\ TLL12		SN304100 and u	•	
79306540	SWITCH BOARD	/ 10-12	15019305	RD6.8JB2	(zener)	
70000040	(pcb 2291057704	\ TIL12		SN 304100 and t	-	
79307510	MAIN BOARD	, 10-12	15019128	MA27WB	(varistor)	
, 555, 5.5	(pcb 2291088802)	TI I-12H	45040000	SN 304100 and t	•	
79307520	SWITCH BOARD	10-1211	15019306	RD7.5JB2	(zener)	TU-12H
, 550, 525	(pcb 2291088802)	TU-12H	15019302	RD5.1JB2	(zener)	TU-12H
	(pos 2201000002)	10-1211	LED			
TRIMMER			15029142	GL-107R5	(red, 7-array	(LED)
13299151	H0651A009 2.2kB		15029144	SLP-144-40	(red)	
			15029143	SLP-139B	(red, TUNIN	IG GUIDE)

TU-12 Second Edition

SPECIFICATIONS

Power Consumption: 9V DC @ 20mA

Tuning Range : C₁ (32.70Hz) to B₅ (987.77Hz)


Accuracy : ±1 cent

Master Oscillator : Quartz (3.579545MHz)

Standard Pitch Dimensions : 440 to 445Hz 1Hz steps

: 145(W) x 35(H) x 53(D)mm 5-7/16 x 1-3/8 x 2-1/16 in

Weight : 170g 6 oz



RESISTOR

13789114D0 CRB25DY 7.68k 0.5% (metal film) 13769262D0 CRB25FX 125k 1% (metal film) 13729490D0 ELR-25G 250k 2% (vertical mount) 13719491D0 ELR-25J 500k 5% (vertical mount)

TRANSISTOR

15129108 2SC945-P (or 15129114 2SC1815-GR) 15139116 2SK118-O (FET)

OTHERS


2225020200 Shield Plate

CHANGES ON TU-12 MAIN BOARD

D8, C13 and Q4 are added in later versions for improvement.

Upward compatible change, later versions can be a substitutive for predecessor(s).


SN up to 294000 MAIN BOARD 79306510 (pcb 2291057701)



SN 304100-390895 (pcb 2291057702)

SN 390896-up (pcb 2291057704)

MAIN BOARD 79306530



TU-12|-1

METER CALIBRATION

CAUTION: KEEP PITCH SWITCH ON DURING ADJUSTMENT, OR TU-12H ENTERS NORMAL MODE. While pushing PITCH, turn power ON (L or H).

Adjust RT1 for 440Hz.

SWITCH BOARD


79307520


(pcb 2291088802)

MAIN BOARD

79307510

(pcb 2291088802)





D1 : S5500G D2 : MA27WB D3 : RD7.5JB2

: RD6.8JB2

D7,8 : SLP-139B D9 : RD5.1JB2 Q1,2:2SC945-P Q3,4:2SK118-0 IC1 : LA6458S IC2 : MBR1012-523 IC3 : LC7900 IC4 : BA634 **TU-12**

METER CALIBRATION

CAUTION: KEEP PITCH SWITCH ON DURING ADJUSTMENT, OR TU-12 ENTERS NORMAL MODE. While pushing PITCH, turn power ON (GUITAR or CHROMATIC).

Adjust CR1 for 440Hz.

SWITCH BOARD

79306540

(pcb 2291057704)

SN 390896-up

compatible with predecessors.

MAIN BOARD

79306530

(pcb 2291057704)

